

PERFORATED HANGER

Fitment guide 50% & 100% utility units.



CONTENTS


1. Getting Started:	2
1.1. Product contents:	2
2. Fitment guide:	2
2.1. Tools required for fitment:	3
2.2. Step 1 – Locate & prepare fitment position:	3
2.3. Step 2 – Position and install the perforated hanger:	3
2.4. Step 3 – Repeat step 2 for installation of multiple perforated hangers:	4
3. Notes:	4

SHOULD YOU HAVE ANY ENQUIRIES ABOUT THE FITMENT, FEEL FREE TO CONTACT US



1. Getting Started:

1.1. Product contents:



A. Perforated hanger assembly	x 1
B. M6 x 20 Socket head button screw	x 4
C. M6 Spring washer	x 4
D. M6 Flat Washer	x 4

2. Fitment guide:



Be aware of the edges on all sheet metal components and take extra care during handling.



Ensure that the area where the perforated hanger will be installed is free from any obstructions.

The perforated hanger can only be installed above a Rhinoman utility drawer on selected vehicles, namely: Isuzu, Nissan Navara H60, Land Cruiser, Amarok Gen 6, Hilux Revo, Tundra, Tacoma, Ranger (2011-2022), Ranger F150, Ranger F250, Gladiator, Dodge RAM.

PLEASE
NOTE...

Torque all M6 fasteners to 10.5Nm.

PLEASE
NOTE...

The installation of the perforated hanger will require two people for ease of alignment.

SHOULD YOU HAVE ANY ENQUIRIES ABOUT THE FITMENT, FEEL FREE TO CONTACT US

2.1. Tools required for fitment:

ALLEN KEY WRENCH




- 1 x 4mm Allen Key

2.2. Step 1 – Locate & prepare fitment position:

**PLEASE
NOTE...**

- All 50% utilities can fit a minimum total of 2 x perforated hangers.
- All 100% utilities can fit a minimum total of 4 x perforated hangers.

- All utility units have pre-cut holes to position the perforated hanger either at the top or bottom of the rear panel. Choose a desired position.
- Once the desired position is determined, remove 4 x of the allocated press-out pieces accordingly.



2.3. Step 2 – Position and install the perforated hanger:

- Place the perforated hanger on the inside onto the rear panel of the utility and align the riv-nut holes with the previously pressed out holes.
- From the outside of the utility, fasten 1 x M6 x 20 Button head screw, 1 x M6 spring washer and 1 x M6 flat washer into each riv-nut as illustrated in Fig. 2.3.1





Fig. 2.3.1

SHOULD YOU HAVE ANY ENQUIRIES ABOUT THE FITMENT, FEEL FREE TO CONTACT US


2.4. Step 3 – Repeat step 2 for installation of multiple perforated hangers:

- Ensure that the additional holes for the additional perforated hangers are pressed out.
- 50% Utilities can fit perforated hangers above/below another.
- 100% utilities can fit perforated hanger left-or-right of the utility and above/below another.

POSITIONS FOR MULTIPLE PERFORATED HANGERS AS BELOW:



50% Utility



100% Utility

3. Notes:

- You have now successfully completed the fitment of your Rhinoman perforated hanger.
- Confirm that all the fitment screws have been properly tightened one last time.
- Be sure to check at least bi-monthly that all the screws are still properly tightened.

SHOULD YOU HAVE ANY ENQUIRIES ABOUT THE FITMENT, FEEL FREE TO CONTACT US